

---

© Copyright 9/30/2009 Justin M. Coslor

**“Power” in the Space Time Continuum.**

**I** = 1 cycle of motion, and **space** allows for motion. (Traditionally, **I** = Intensity of ElectroMotiveForce measured in Amperes.)

Space is curved.

**E** = 1 unit of **time**. Meaning the distance through the origin of the spiral per unit of time. (Like a Helix.)

Time is a function of motion.

So time is proportional to motion. (Traditionally, **E** = Energy measured in Volts.)

**R** = the **pathway** for each cycle of motion. (Traditionally, **R** = Resistance (also called the load), measured in Ohms.) ... Another word for “pathway” in a closed circuit is “Continuum” or “Context”.

A closed circuit is a **pathway** of **space** through **time**.

That means that **Power** = the quantity of the space\_time\_pathway in terms of units of quanta, such as quarks, which are small loops and spirals and knots of energy.

(Traditionally **P** = Power measured in Watts.)

(10/1/2009 update by Justin M. Coslor – this is all in terms of Ohm's Law.

Exponents are perpendicular dimensions in curved space such as spirals around lines and loops and spirals...See “**Sine Spiral Graphing**”: © Justin M. Coslor 1996-1997. Fractional Exponents are partition sections of motion cycles divided into units partition sections of the fractional exponent denominator, i.e. root equations and logarithms represented geometrically via trigonometry orbits.)

---